

BIXOLON

Software Manual

BIXOLON Utility

Windows

Ver. 1.00

www.bixolon.com

Copyright

© BIXOLON Co., Ltd. All rights reserved.

This user manual and all property of the product are protected under copyright law. It is strictly prohibited to copy, store, and transmit the whole or any part of the manual and any property of the product without the prior written approval of BIXOLON Co., Ltd.

The information contained herein is designed only for use with this BIXOLON product. BIXOLON is not responsible for any direct or indirect damages, arising from or related to use of this information.

- The BIXOLON logo is the registered trademark of BIXOLON Co., Ltd.
- All other brand or product names are trademarks of their respective companies or organizations.

BIXOLON Co., Ltd. maintains ongoing efforts to enhance and upgrade the functions and quality of all our products.

In the following, product specifications and/or user manual content may be changed without prior notice.

Caution

Some semiconductor devices are easily damaged by static electricity. You should turn the printer "OFF", before you connect or remove the cables on the rear side, in order to guard the printer against the static electricity. If the printer is damaged by the static electricity, you should turn the printer "OFF".

Table of contents

Copyright	2
1. Introduction	5
2. Supported OS	5
3. Supported Printers	6
4. Ready to use	9
5. Common Guide	10
5-1 Printer Connection Method	10
5-1-1 USB.....	11
5-1-2 Bluetooth.....	12
5-1-3 Parallel.....	13
5-1-4 LAN/WLAN	14
5-1-5 Serial	15
5-2 Printer Network Setting.....	16
5-2-1 LAN/WLAN Setting.....	16
5-2-2 WLAN Advanced	19
5-2-3 Simple Wi-Fi Connect(SWC).....	26
5-3 Printer Info.....	29
6. POS Printer Guide	30
6-1 Printer Settings	30
6-1-1 General Settings	30
6-1-2 Serial setting.....	33
6-1-3 Bluetooth configuration	34
6-1-4 Blackmarks setting.....	36
6-1-5 Paper Save Mode	37
6-1-6 Statistics.....	38
6-1-7 Memory Switch.....	39
6-2 NV Image Tool.....	40
6-2-1 Add the NV Image.....	41
6-2-2 Image Option Settings	42
6-2-3 Download the NV Image	43
6-2-4 Print the NV Image.....	44

6-3 Command Test.....	45
6-4 File Transfer	46
7. Mobile-POS Printer Guide.....	47
7-1 Printer Settings	47
7-1-1 General Settings	47
7-1-2 Interface	49
7-2 NV Image Tool.....	50
7-2-1 Add the NV Image.....	51
7-2-2 Download the NV Image	52
7-2-3 Print the NV Image.....	52
7-3 File Transfer	53
8. Label / Mobile-Label Printer Guide	54
8-1 Printer Settings	54
8-1-1 General Settings	54
8-1-2 Language	56
8-1-3 Interface	57
8-1-4 Real-Time Clock.....	58
8-1-5 Power	59
8-1-6 RFID.....	60
8-1-7 Statistics/USB	61
8-2 Calibration Settings	62
8-3 Print Quality Settings	63
8-4 Downloader	64
8-4-1 PCX Files.....	64
8-4-2 Image Files	66
8-4-3 TTF → Bitmap Font	67
8-4-4 TTF → Vector Font.....	68
8-4-5 BAS Files.....	70
8-4-6 File Transfer	72
8-5 Printer Tool	73
8-6 Command Test.....	74

1. Introduction

This manual describes how to use the BIXOLON Utility (hereinafter referred to as The Utility). Depending on the printer type or model, the supported menus are different. You can check type (or model) of your printer in Supported Printers.

2. Supported OS

The following OS are supported for usage.

- Microsoft Windows 7 (32bit/64bit)
- Microsoft Windows 8 (32bit/64bit)
- Microsoft Windows 8.1 (32bit/64bit)
- Microsoft Windows 10 (32bit/64bit)
- Microsoft Windows 11 (64bit)

3. Supported Printers

POS Printer		
Model	DPI	Max Printable Width
SRP-E300	180 dpi	512 dots
SRP-E302	203 dpi	576 dots
SRP-Q200	203 dpi	434 dots
SRP-Q300	180 dpi	512 dots
SRP-Q300II	203 dpi	576 dots
SRP-Q302	203 dpi	576 dots
SRP-QE300	180 dpi	512 dots
SRP-QE302	203 dpi	576 dots
SRP-S300	203 dpi	576 dots
SRP-380	180 dpi	512 dots
SRP-382	203 dpi	576 dots
SRP-383	300 dpi	864 dots
SRP-380II	180 dpi	512 dots
SRP-382II	203 dpi	576 dots
SRP-330II	180 dpi	512 dots
SRP-332II	203 dpi	576 dots
SRP-330III	180 dpi	512 dots
SRP-332III	203 dpi	576 dots
SRP-F310II	180 dpi	512 dots
SRP-F312II	203 dpi	576 dots
SRP-F313II	203 dpi	640 dots
SRP-350III	180 dpi	512 dots
SRP-352III	203 dpi	576 dots
SRP-350plusIII	180 dpi	512 dots
SRP-352plusIII	203 dpi	576 dots
SRP-350V	180 dpi	512 dots
SRP-352V	203 dpi	576 dots
SRP-350plusV	180 dpi	512 dots
SRP-352plusV	203 dpi	576 dots
SRP-340II	180 dpi	512 dots
SRP-342II	203 dpi	576 dots
SRP-B300	203 dpi	576 dots (42CPL: 546dots)
SRP-S320	203 dpi	576 dots
SRP-S3000	203 dpi	576 dots
SRP-S200	203 dpi	434 dots
BK3-3	203 dpi	576 dots
BK3-2	203 dpi	432 dots
BK5-3	203 dpi	576 dots
SPP-200	203 dpi	576 dots
G30	203 dpi	576 dots

Windows BIXOLON Utility

Mobile-POS Printer		
Model	DPI	Max Printable Width
SRP-200III	203 dpi	384dot
SRP-R210	203 dpi	384dot
SPP-R220	203dpi	384dot
SPP-R310	203 dpi	576dot
SPP-R318	203 dpi	576dot
SPP-R400II	203 dpi	832dot
SPP-R410	203 dpi	832dot
SPP-R418	203 dpi	832dot
SPP-C200	203 dpi	384dot
SPP-C300	203 dpi	576dot

Label Printer				
Model	X Position		Y Position	
	Min	Max	Min	Max
SLP-TX400	0	864	0	Label Length
SLP-TX400R	0	864	0	Label Length
SLP-TX403	0	1248	0	Label Length
SLP-TX403R	0	1248	0	Label Length
SLP-DX420	0	864	0	Label Length
SLP-DX423	0	1248	0	Label Length
SLP-DX220	0	432	0	Label Length
SLP-DX223	0	672	0	Label Length
SLP-TX420	0	864	0	Label Length
SLP-TX423	0	1248	0	Label Length
SLP-TX220	0	432	0	Label Length
SLP-TX223	0	672	0	Label Length
SLP-DL410	0	864	0	Label Length
SLP-DL413	0	1248	0	Label Length
SRP-770III/E770III	0	832	0	Label Length
SRP-S3000_LABEL	0	576	0	Label Length
XT5-40	0	832	0	Label Length
XT5-40NR	0	832	0	Label Length
XT5-43	0	1248	0	Label Length
XT5-43NR	0	1248	0	Label Length
XT5-46	0	2496	0	Label Length
XT5-46NR	0	2496	0	Label Length
XT3-40	0	864	0	Label Length
XT3-43	0	1248	0	Label Length
XD3-40d	0	832	0	Label Length
XD3-40t	0	832	0	Label Length
XD5-40d	0	864	0	Label Length
XD5-43d	0	1248	0	Label Length
XD5-40t	0	864	0	Label Length
XD5-40tR	0	864	0	Label Length

Windows BIXOLON Utility

XD5-43t	0	1248	0	Label Length
XD5-43tR	0	1248	0	Label Length
XL5-40CT	0	864	0	Label Length
XL5-43CT	0	1248	0	Label Length
XQ-840	0	832	0	Label Length
XQ-843	0	1248	0	Label Length
SPP-L3000	0	576	0	Label Length
SPP-L310	0	576	0	Label Length
SPP-L410	0	832	0	Label Length
SRP-770II/E770II	0	832	0	2600
SLP-T400	0	864	0	8000
SLP-T403	0	1248	0	5200
SLP-D420	0	864	0	8000
SLP-D423	0	1248	0	5200
SLP-D220	0	432	0	8000
SLP-D223	0	672	0	5200
XF3-40	0	864	0	8000

Mobile-Label Printer				
Model	X Position		Y Position	
	Min	Max	Min	Max
XM7-40	0	832	0	Label Length
XM7-40R	0	832	0	Label Length
XM7-20	0	384	0	Label Length
XM7-30	0	576	0	Label Length


4. Ready to use

1. Download the Utility

You can download the latest version of the Utility from www.bixolon.com.

2. The Utility Language Selection

Please select a language.



The screenshot displays the Bixolon Utility v1.0.0 window. On the left, a 'Port' selection area shows 'No Available Ports'. On the right, the 'Interface' section has radio buttons for USB (selected), Bluetooth, Parallel, LAN/WLAN, and Serial. Below this, the 'Language' section features a dropdown menu currently set to 'English (English)', which is highlighted by a red rectangular box. At the bottom right are 'Connect', 'Disconnect', and 'Exit' buttons. The footer contains the copyright notice: 'Copyright (c) BIXOLON CO., LTD. All Rights Reserved.'

5. Common Guide

5-1 Printer Connection Method

- You can connect to the printer with following interface type.
 - USB
 - Bluetooth
 - Parallel
 - LAN/WLAN
 - Serial




The support interface may vary depending on the printer model.

Windows BIXOLON Utility


5-1-1 USB

- 1) Connect your printer to host with USB cable.
- 2) Select the USB in the interface menu.
- 3) The available ports appear in the list.
- 4) Double-click the port or click the connect button.




5-1-2 Bluetooth

- 1) Add a printer on Add a Bluetooth device menu in Windows.
- 2) Check the COM port of the printer.
(You can check the port at in Control > Device and printer > Properties > Hardware menu)
- 3) Select the Bluetooth in the interface menu.
- 4) The available ports appear in the list.
- 5) Double-click the port or click the Connect button.



5-1-3 Parallel

- 1) Connect your printer to host with Parallel cable.
- 2) Select the Parallel in the interface menu.
- 3) The available ports appear in the list.
- 4) Double-click the port or click the Connect button.



5-1-4 LAN/WLAN

- 1) Select the LAN/WLAN in the interface menu.
- 2) Click the Search button.
- 3) Select the item in the list.
- 4) If the Manual button is checked, User can input the IP.

BIXOLON Utility v1.0.0

#	IP	MAC	Port
1	192.168.0.8	00:15:94:C8:CA:1F	9100
2	192.168.0.42	00:15:94:E0:D5:CE	9100

☐ Manual
IP : 192 . 168 . 0 . 1
port : 9100

Search
Settings
SWC

Interface
☐ USB ☐ Bluetooth
☐ Parallel ☒ LAN/WLAN
☐ Serial

Language
English (English) ▼

Connect Disconnect

Exit

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

5-1-5 Serial

- 1) Connect your printer to host with Serial cable.
- 2) Select the Serial in the interface menu.
- 3) Check the COM port number and serial information of the printer.
- 4) Select port options and click the connect button.

The screenshot displays the BIXOLON Utility v1.0.0 application window. The interface is divided into several sections. On the left, there is a list of serial port settings, each with a label and a dropdown menu: Port (set to COM1), Baud Rate (set to 9600), Data Bits (set to 8), Parity (set to None), Stop Bits (set to 1), and Flow Control (set to DTR/DSR). On the right, there is an 'Interface' section with four radio buttons: USB, Bluetooth, Parallel, and Serial (which is selected). Below the interface section is a 'Language' dropdown menu set to 'English (English)'. At the bottom right, there are two buttons: 'Connect' and 'Disconnect'. Below these buttons is an 'Exit' button. At the very bottom of the window, a copyright notice reads: 'Copyright (c) BIXOLON CO., LTD. All Rights Reserved.'

BIXOLON Utility v1.0.0

Port : COM1

Baud Rate : 9600

Data Bits : 8

Parity : None

Stop Bits : 1

Flow Control : DTR/DSR

Interface

☐ USB ☐ Bluetooth

☐ Parallel ☐ LAN/WLAN

☒ Serial

Language

English (English)

Connect Disconnect

Exit

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

5-2 Printer Network Setting

- To configure the **Network settings**, the Ethernet cable should be connected to the Printer while the host (PC) and printer are connected to the same network.
For configuring the **WLAN settings**, the host and printer should be connected to the same Wi-Fi Access Point or connected to each other using Wi-Fi Direct (P2P).

5-2-1 LAN/WLAN Setting

Network required for communication by searching for printers connected to the same wired/wireless network as the host You can set the information.

1) Please click the Search button.

BIXOLON Utility v1.0.0

#	IP	MAC	Port

☐ Manual

IP : 192 . 168 . 0 . 8

port : 9100

Search

Settings

SWC

Interface

☐ USB☐ Bluetooth☐ Parallel☒ LAN/WLAN☐ Serial

Language

English (English) ▼

Connect

Disconnect

Exit

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Windows BIXOLON Utility

2) The printer(s) that uses the same network at the host is displayed.

BIXOLON Utility v1.0.0

#	IP	MAC	Port
1	192.168.0.8	00:15:94:C8:CA:1F	9100
2	192.168.0.42	00:15:94:E0:D5:CE	9100

☐ Manual

IP : 192 . 168 . 0 . 1

port : 9100

Search

Settings

SWC

Interface

☐ USB ☐ Bluetooth

☐ Parallel ☒ LAN/WLAN

☐ Serial

Language

English (English) ▼

Connect Disconnect

Exit

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

3) Double-click the item or click the settings button.

BIXOLON Utility v1.0.0

#	IP	MAC	Port
1	192.168.0.8	00:15:94:C8:CA:1F	9100
2	192.168.0.42	00:15:94:E0:D5:CE	9100

☐ Manual

IP : 192 . 168 . 0 . 1

port : 9100

Search

Settings

SWC

Interface

☐ USB ☐ Bluetooth

☐ Parallel ☒ LAN/WLAN

☐ Serial

Language

English (English) ▼

Connect Disconnect

Exit

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

4) Click the save button after set the options.

LAN/WLAN Configuration

IP Address Configuration

☒ Auto(DHCP)

IP

Subnet Mask

GateWay

Port

[0 - 32767]

Inactivity Time (Sec.)

[0 - 3600]



If DHCP server is not supported, you have to assign IP address manually. Contact your network administrator for the assignable IP address.

Settings	Description			
IP Address Assignment Method	Assign IP address manually or automatically through DHCP. If the network does not support DHCP, you must assign the IP address manually.			
IP Address	This information is required for LAN/WLAN communication and a unique IP address must be entered. The communication port is set to 9100 by default. You have to change the port number via reference below table to use another port.			
Subnet Mask				
Gateway				
Port Number	Port Number	Description	TCP/UDP	Notes
	9100, 6101, 9300	Printing	TCP	Used for printing
	80	HTTP	TCP	Web page
	3337, 9000	Device Management	UDP	Bixelon Device Discovery/Setting
Inactivity Time	If there is no communication between the host and printer during the set period of time, the connection will be closed automatically. If set to 0, this function is disabled.			

5-2-2 WLAN Advanced

This menu supports option setting regarding to WLAN.



This menu is available only when the printer is connected to USB.

1) Please click the Get button.

BIXOLON Utility v1.0.0

Printer Info

▼ Printer Setting

- General Settings
- Language
- Interface
- Power
- Statistics / USB
- WLAN Advanced

Calibration Settings

Print Quality Settings

► Downloader

Printer Tool

Command Test

WLAN Advanced

+

WLAN Basic Configuration

SSID	lyjang_wifi_5G
PSK Key	*****

Get

User settings

Save

Load

Reset

Save


Close

BIXOLON


Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Windows BIXOLON Utility

2) Please click the button(...) and choice the SSID what you want.



3) Please click the button(...) and input the SSID Password.



4) Please click the save button after option setting.

5) You can save or load the current settings as a file.

Windows BIXOLON Utility

WLAN Basic Config.	Description
SSID(Service Set Identifier)	A unique identifier that is included in all data header sent via WLAN. A maximum of 32 characters can be entered.
WLAN Mode	Choose one of the following WLAN connection methods: <ul style="list-style-type: none"> - Infrastructure - Ad-Hoc - Wi-Fi Direct - Soft AP (Access Point) ※ Certain models do not support Wi-Fi Direct and Soft AP.
Ad-Hoc Channel	Choose between 1 and 14.
Wi-Fi Direct Channel	Choose 1, 6 or 11.
Wi-Fi Direct PIN Code	Enter 4 or 8 digit number.

WLAN Security	Description
Authentication	Choose one of the following authentication methods: <ul style="list-style-type: none"> - Open System - Shared Key - WPA-PSK - WPA2-PSK - WPA-EAP - WPA2-EAP
Encryption	Choose one of the following encryption methods: <ul style="list-style-type: none"> - None - WEP-64 - WEP-128 - TKIP - AES - AES + TKIP
WEP-64 Key	Enter 5-letter key or 10-digit hexadecimal number. ※ Only characters that can be entered on the ASCII code table are allowed.
WEP-128 Key	Enter 13-letter key or 26-digit hexadecimal number. ※ Only characters that can be entered on the ASCII code table are allowed.
PSK Key	Enter at least 8-letter key. ※ Only characters that can be entered on the ASCII code table are allowed. A maximum of 63 characters can be entered.

Windows BIXOLON Utility

EAP Mode	Choose one of the following EAP Modes: <ul style="list-style-type: none"> - EAP-PEAP - EAP-TTLS - EAP-TLS - EAP-LEAP - EAP-FAST
EAP ID	Enter a maximum of 32 characters for EAP ID.
EAP Password	Enter a maximum of 32 characters for EAP password.

IP Address Configuration	Description																			
IP Address Assignment	Assign the IP address manually or automatically through DHCP. If the network does not support DHCP, you have to assign IP address manually.																			
IP Address	This information is required for LAN/WLAN communication and unique IP address must be entered. The communication port is set to 9100 by default. You have to change the port number via reference below table to use another port.																			
Subnet mask																				
Gateway																				
Port Number	<table><tr><th>Port Number</th><th>Description</th><th>TCP/UDP</th><th>Notes</th></tr><tr><td>9100, 6101, 9300</td><td>Printing</td><td>TCP</td><td>Used for printing</td></tr><tr><td>80</td><td>HTTP</td><td>TCP</td><td>Web page</td></tr><tr><td>3337, 9000</td><td>Device Management</td><td>UDP</td><td>Bixolon Device Discovery/ Setting</td></tr></table>				Port Number	Description	TCP/UDP	Notes	9100, 6101, 9300	Printing	TCP	Used for printing	80	HTTP	TCP	Web page	3337, 9000	Device Management	UDP	Bixolon Device Discovery/ Setting
Port Number	Description	TCP/UDP	Notes																	
9100, 6101, 9300	Printing	TCP	Used for printing																	
80	HTTP	TCP	Web page																	
3337, 9000	Device Management	UDP	Bixolon Device Discovery/ Setting																	

Windows BIXOLON Utility

System Configuration	Description	
System Name	This string indicates the WLAN printer. A maximum of 64 characters can be entered. ※ This string may not be shown in certain printers.	
User ID	User ID and Password are used to access a printer from a web browser. A maximum of 32 characters can be entered.	
User Password		
Inactivity Time	If there is no communication between the host and printer during the set period of time, the connection will be closed automatically. The value can be set between 0 and 3600 seconds (1 hour) by a unit of second. If set to 0, this function is disabled.	
Wireless Frequency	2.4GHz	2.4GHz is used for frequency.
	5.0GHz	5.0GHz is used for frequency.
	2.4GHz/5.0GHz (Priority: 2.4GHz)	Both 2.4GHz/5.0GHz are used. (2.4GHz has a higher priority.)
	2.4GHz/5.0GHz (Priority: 5.0GHz)	Both 2.4GHz/5.0GHz are used. (5.0GHz has a higher priority.)
	※ You may not be able to choose frequency in certain printers.	

Windows BIXOLON Utility

Protocol	Description
HTTPS	HTTPS (Hypertext Transfer Protocol over Secure Socket Layer) is a security enhanced version of HTTP. You can configure WLAN settings using the HTTPS protocol on a web browser. ※ This may not be supported by certain printers.
TELNET	Using the TELNET protocol, you can configure WLAN settings by TELNET interaction. ※ This may not be supported by certain printers.
FTP	Using the FTP protocol, you can configure WLAN settings by editing the file related to WLAN information. ※ This may not be supported by certain printers.
SNMP	MIB-2 (management information base-2) information can be read and written. ※ This may not be supported by certain printers.

SNMP	Description
SNMP Community Name (Read)	This string indicates the name for trap reading.
SNMP Community Name (Write)	This string indicates the name for trap writing.
SNMP Trap Community	This string indicates the name for trap community.
SNMP Trap IP Address	This string indicates IP address for trap Server.

Windows BIXOLON Utility

Certificate Upload	Description
Certificate Type	Select the type of certificate to download to the printer. <ul style="list-style-type: none">- CA (Certificate Authority)- Client Key- Client PEM
Certificate File	Start downloading by selecting the type of certificate to download to the printer.

Certificate Name	Description
CA	A string representing the name of each downloaded certificate.
Client Key	
Client PEM	Each certificate name is a file name used to download the certificate.

5-2-3 Simple Wi-Fi Connect(SWC)

Connect a printer set to Simple Wi-Fi Connect mode (hereinafter SWC mode) to connect the surrounding AP information. You can receive and set the selected AP information to the printer.



To use the Simple Wi-Fi Connect feature, the printer must support the SWC feature and the host (typically a PC) must also support WLAN.

1) Please click the SWC button.

The screenshot shows the BIXOLON Utility v1.0.0 window. On the left, there is a table with columns: #, IP, MAC, and Port. Below the table are input fields for IP (192.168.0.1) and port (9100), a checkbox for 'Manual', and buttons for 'Discovery', 'Settings', and 'SWC'. The 'SWC' button is highlighted with a red rectangle. On the right, there are sections for 'Interface' (with radio buttons for USB, Bluetooth, LAN/WLAN, Parallel, and Serial), 'Language' (with a dropdown menu set to 'English (English)'), and buttons for 'Connect', 'Disconnect', and 'Exit'. At the bottom, there is a copyright notice: 'Copyright (c) BIXOLON CO., LTD. All Rights Reserved.'

2) Run SWC Mode after the printer is powered on.

3) Check the SWC Mode status. and click the Wi-Fi Search button.

The screenshot shows the 'Simple Wi-Fi Connection' dialog box. It has a title bar 'Simple Wi-Fi Connection' and a button 'Wi-Fi Search' which is highlighted with a red rectangle. Below the button is a table with columns: #, SSID, Security, and Quality.



When you click the Scan Wi-Fi button, the host attempts to connect to the printer's wireless network.

4) Please select AP item when the list up.

Simple Wi-fi Connection

Wi-Fi Search

#	SSID	Security	Quality
74	jyjang_wifi	WPA2	Excellent
75		WPA2	Excellent
76		WPA2	Poor
77		WEP64	Good
78		WPA2	Excellent
79		WPA2	Good
80		WPA2	Excellent
81		WPA2	Excellent
82		WPA2	Excellent
83		WPA2	Excellent
84		WPA2	Excellent

Model

XM7-40

S/N

STDBCEKS23040002

SSID

jyjang_wifi

P/W

Security

WPA2

☒ Auto(DHCP)

IP

Subnet Mask

GateWay

Save

Cancel

Windows BIXOLON Utility

5) Input SSID password and click the save button.

Simple Wi-fi Connection

Wi-Fi Search

#	SSID	Security	Quality
74	jyjang_wifi	WPA2	Excellent
75		WPA2	Excellent
76		WPA2	Poor
77		WEP64	Good
78		WPA2	Excellent
79		WPA2	Good
80		WPA2	Excellent
81		WPA2	Excellent
82		WPA2	Excellent
83		WPA2	Excellent
84		WPA2	Excellent

Model

XM7-40

S/N

STDBCEKS23040002

SSID

jyjang_wifi

P/W

Security

WPA2

☐ Auto(DHCP)

IP

192 . 168 . 0 . 1

Subnet Mask

255 . 255 . 255 . 0

GateWay


192 . 168 . 0 . 1

Save

Cancel

5-3 Printer Info

- This menu supports printer information and print self-test or codepage.



Printer Type of supports Code page button
: POS Printer / POS

6. POS Printer Guide

6-1 Printer Settings

6-1-1 General Settings

This menu supports general option settings.

BIXOLON Utility v1.0.0

Printer Info

- Printer Setting
 - General Settings
 - Serial communication s
 - Paper Save Mode
 - Memory switch
 - WLAN Advanced
- NV Image Tool
- Command Test
- File Transfer

General Settings

Code page

☐ 1-Byte

☒ 2-Bytes

KS5601(Korean)

Speed

Speed 8 [Default]

Density

Density 4 [Default]

Font

Font A (12x24)

Emulation

Emulation 2

Printing width selection

72mm (576dot) [Default]

Printing column selection

48 Column [Default]

Cutting Mode

Partial cut

Bezel LED setting

ON [While printing, or an error]

Save

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Close



Depending on the printer model, the type, range of options may vary.

Windows BIXOLON Utility

Settings	Description
1)Codepage	Printer default codepage
Font	Printer device font
Speed & Density	Printing speed and density
Power Save Mode	Mode and entrance time setting
Cutting Mode	Cutting method after printing
Cutter Depth Adjustment	Length of paper cut after printing
ICS	International Character Set
Set buzzer ctrl after cutting	Whether and how many times the buzzer after cutting
Printing Width Selection	Maximum printable paper width
Printing Column Selection	Maximum printable paper column
Bezel LED Setting	Set bezel LED control
2)Emulation	Printer emulation
3)Char 90° Rotation	Print characters rotated 90° to the right
3)Back-feeding Mode	Back-feeding paper for a certain length before starting printing
4) Auto feed in idle mode	Paper feeding at regular time intervals when in idle mode
4)BM Cutting Position	Set cutting position as default position or BM position
4)Speaker on/off	set the built-in speaker on/off
4)Auto Cali(BM mode)	Automatically detects BM when feeding paper

1) Unicode encoding support model

: SRP-380/382/383
SRP-Q300/302

2) Supported Models

: BK3-3, BK3-2, BK5-3, SRP-S3000

If you want to use BIXOLON's S/W, please set it to 'emulation 2'.
SRP-S3000 model must be rebooted after the emulation has been changed, and the printer type is set based on the emulation.



3) Supported models

: SRP-S300L/S300T/S320/SRP-S3000/S200, G30
SRP-S320/S3000/S200 model is not supported Char 90° Rotation.

4) Supported models

: SRP-S320/S3000/S200
SRP-S3000 model is only supports Speaker On/Off.

6-1-2 Serial setting

This menu supports option setting regarding to Serial interface.

BIXOLON Utility v1.0.0

Printer Info

▼ Printer Setting

- General Settings
- **Serial setting**
- Blackmarks setting
- Paper Save Mode
- Memory switch
- WLAN Advanced

NV Image Tool

Command Test

File Transfer

Serial setting

Setting Method

☐ Memory switch

☒ DIP switch

Baud Rate

115200

Data Bits

8

Parity

NONE

Flow Control

DTR/DSR

Reception Error

Prints?'

Save

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Close

Supported Models



: SRP-E300/E302, SRP-Q200, SRP-S320, BK3-3, BK3-2, BK5-3, SPP-200
SRP-S320/S3000/S200, SRP-B300, SRP-380II/382II

Reception Error is only supported for BK3-3, BK3-2, BK5-3, SPP-200.

6-1-3 Bluetooth configuration

This menu supports option settings regarding to Bluetooth configuration.

BIXOLON Utility v1.0.0

Printer Info

▼ Printer Setting

- General Settings

- Serial setting

- Bluetooth configuration

- Blackmarks setting

- Paper Save Mode

- Statistics

- Memory switch

- WLAN Advanced

NV Image Tool

Command Test

File Transfer

Bluetooth configuration

MFi Information

F/W Version :
H/W Version :
Protocol String :
Serial Number :

Authentication & Encryption

☐ Enable ☐ Disable

Operating Mode

BT Module Ver. IFJ-B5

Paring Mode :

Role Mode :

Connection Mode

Auto Re-Connection

☐ Enable ☐ Disable

Re-Count :
Interval :

PIN Code

Device Name

Save

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Close

Windows BIXOLON Utility

Setting	Description
Device Name	Device name displayed during BT pairing
PIN Code	Code required during BT pairing
Authentication & Encryption	If Authentication & Encryption mode is disabled, connection to a device can be done without a Code
Connection Mode	<ul style="list-style-type: none"> - Mode 1: connection possible only with the first device with which connection succeeds - Mode 2: connection with all Bluetooth enabled devices possible via use of a PIN Code - Mode 3: Discovery will be not supported. Use MAC address for connection
MFi Info.	In case of iOS mode, MFi information will be displayed
Auto Re-Connection	Retry setting on Bluetooth can be enabled when connection is released
Paring mode	<ul style="list-style-type: none"> - PIN Code: When BT pairing, uses PIN Code exchange - SSP(Just works): When BT pairing, uses SSP mechanism - SSP(Numeric Comparison): When BT pairing, uses SSP which is added Numeric Comparison step. * SSP(Simple Secure Paring)
Role Mode	<ul style="list-style-type: none"> - Classic - BLE(Bluetooth Low Energy) - Classic & BRD

Supported Models

: SRP-350IIIBE, SRP-350plusIII/352plusIII/350plusV/352plusV, SRP-380/382/383/380II/382II, SRP-F310II/F312II/F313II, SRP-Q300/Q302/Q200, SRP-Q300II, SRP-S300/S320, G30



Supported models for BT paring mode and role mode

(BT module Ver. IFJ-Ba)

SRP-350plusIII/352plusIII/350plusV/352plusV, SRP-Q300/Q302, SRP-Q300II, SRP-S300/S320, SRP-380II/382II, G30

6-1-4 Blackmarks setting

This menu supports option settings regarding to Blackmark.

BIXOLON Utility v1.0.0

Printer Info

▼ Printer Setting

- General Settings
- Serial setting
- Blackmarks setting
- Paper Save Mode
- Memory switch
- WLAN Advanced

NV Image Tool

Command Test

File Transfer

Blackmarks setting

Auto-load powering on

☐ Default

☒ 1st Memory

(mm)

Length between Blackmark

177

Cutting position after Blackmark

0 (-19 ~ 177)

Blackmark sensor

Left [Default]

Reset Save

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Close

Supported Models

: BK3-3, BK3-2, BK5-3



For BK3-3, BK3-2 models, this menu is only available in Blackmark mode (DIP Switch 1-4 On), and only 'Auto-load powering on' options can be set.

6-1-5 Paper Save Mode

This menu supports option settings regarding to Paper Save Mode.

The screenshot shows the 'BIXOLON Utility v1.0.0' window. On the left is a sidebar menu with 'Printer Setting' expanded, showing options like General Settings, Serial setting, Bluetooth configuration, Blackmarks setting, Paper Save Mode (highlighted), Statistics, Memory switch, and WLAN Advanced. Below these are 'NV Image Tool', 'Command Test', and 'File Transfer'. The main area is titled 'Paper Save Mode'. It contains two sections: 'Paper Save Level' with radio buttons for 'Disable' (selected), 'LEVEL 1', 'LEVEL 2', and 'LEVEL 3'; and 'Cutting position correction' with radio buttons for 'Enable' and 'Disable' (selected). A 'Save' button is at the bottom right of the main area. The footer contains the 'BIXOLON' logo, the copyright notice 'Copyright (c) BIXOLON CO., LTD. All Rights Reserved.', and a 'Close' button.


Supported Models

: BGT-100P/102P, SRP-330II/332II/330III/332III, SRP-340II/342II, SRP-350III/352III/350V/352V, SRP-350plusIII/352plusIII/350plusV/352plusV, SRP-380/382/383/380II/382II, SRP-E300/E302, SRP-F310II/F312II/F313II, SRP-Q300/Q302/Q200, SRP-QE300/QE302, SRP-Q300II, SRP-S300/S320/S3000/S200, G30, BK3-3, BK3-2, BK5-3, SPP-200, SRP-B300



6-1-6 Statistics

This menu supports check or reset the data such as motor feeding, auto cutting.



Depending on the printer model, the screen UI may vary, and some models can initialize data.



Supported models for menu

: SRP-F310II/F312II/F313II, SRP-Q300/Q302, SRP-QE300/QE302
SRP-380/382/383, SRP-Q300II

Supported models for Reset button

: SRP-S320, SRP-380II/382II

6-1-7 Memory Switch

This menu supports virtual memory switch setting and option save as file.

The screenshot shows the BIXOLON Utility v1.0.0 interface. On the left is a sidebar menu with the following items: Printer Info, Printer Setting (expanded), General Settings, Serial setting, Bluetooth configuration, Blackmarks setting, Paper Save Mode, Statistics, Memory switch (highlighted), WLAN Advanced, NV Image Tool, Command Test, and File Transfer. The main area is titled 'Memory switch'. It contains a table with 8 rows, each with a label and a dropdown menu. The labels are: [PIN 1] Print Speed (Set in Printer Setting Tab), [PIN 2] Print Speed (Set in Printer Setting Tab), [PIN 3] Print Speed (Set in Printer Setting Tab), [PIN 4] Reserved, [PIN 5] Reserved, [PIN 6] Print Density (Set in Printer Setting Tab), [PIN 7] Print Density (Set in Printer Setting Tab), and [PIN 8] Print Density (Set in Printer Setting Tab). All dropdown menus are set to 'Disable'. Below the table is a navigation bar with '<<', '1', and '>>' buttons. At the bottom left is a 'User settings' box with 'Save' and 'Load' buttons. At the bottom right are 'Reset' and 'Save' buttons. The footer contains the BIXOLON logo, the copyright notice 'Copyright (c) BIXOLON CO., LTD. All Rights Reserved.', and a 'Close' button.

Label	Value
[PIN 1] Print Speed (Set in Printer Setting Tab)	Disable
[PIN 2] Print Speed (Set in Printer Setting Tab)	Disable
[PIN 3] Print Speed (Set in Printer Setting Tab)	Disable
[PIN 4] Reserved	Disable
[PIN 5] Reserved	Disable
[PIN 6] Print Density (Set in Printer Setting Tab)	Disable
[PIN 7] Print Density (Set in Printer Setting Tab)	Disable
[PIN 8] Print Density (Set in Printer Setting Tab)	Disable

1. User settings


User can save the option as file or load.

2. Reset

User can reset the memory switch.

6-2 NV Image Tool

- This menu supports NV image download to the printer flash memory.



6-2-1 Add the NV Image

Please add an image.

NV Image Tool

No.	Name	Size
1	BIXOLON.bmp	7.5
2	gradation.bmp	13.0

Add

Remove

Reset


Print

Download

BIXOLON®

6-2-2 Image Option Settings

Select an image option.



Support file type

: Bitmap File(.bmp)

Supported Model for Adjustment(Width)

: SRP-380/382/383/380II/382II, SRP-E300/E302, SRP-Q300/Q302, SRP-Q300II, SRP-QE300/QE302, SRP-S300, SRP-S320, SRP-S3000, BK3-3, BK3-2, SRP-B300, BK5-3, SPP-200, G30




Supported Model for Grayscale

: BGT-100P/102P, SRP-330II/332II/330III/332III, SRP-350plusIII/352plusIII/350plusV/352plusV, SRP-380/382/383/380II/382II, SRP-E300/E302, SRP-F310II/F312II/F313II, SRP-Q300/Q302, SRP-QE300/QE302, SRP-Q300II, SRP-S300/ S320/S3000/S200, G30, SRP-B300

6-2-3 Download the NV Image

Please download an image.



1) Select addressing method and click the download button.

6-2-4 Print the NV Image

This menu supports print the NV image function.

The screenshot shows a window titled "BK3-3". On the left is a list box containing the items "00" and "01". To the right of the list box is a "Select" label above a text input field containing "00". Below the input field is a "Print" button. Further down the right side are buttons for "Refresh", "Print", "Print All", "Remove", "Remove All", and "Close".

Item
00
01

Select

00

Print

Refresh

Print

Print All

Remove

Remove All

Close

6-3 Command Test

- This menu supports command test.

BIXOLON Utility v1.0.0

Printer Info
Printer Setting
NV Image Tool
Command Test
File Transfer

Command Test

[Hex] ex : 1d 61 ff 0a ...

Send Clear

Test Print

Files

Save Load

Options

Font	Alignment	Cut & Feed	Line space (0 ~ 255)
Font A	Left	Feed	<input type="checkbox"/> Default
Font B	Center	Partial cut	0
<input type="checkbox"/> Bold	Right	Full cut	Input
<input type="checkbox"/> Underline			

BIXOLON Copyright (c) BIXOLON CO., LTD. All Rights Reserved. Close



You can download the manual on our website and by model
The supported commands may differ slightly.
(www.bixolon.com)

6-4 File Transfer

- This menu supports transfer a file to the printer.

The screenshot displays the "File Transfer" section of the BIXOLON Utility v1.0.0 application. On the left, a sidebar contains navigation links: "Printer Info", "> Printer Setting", "NV Image Tool", "Command Test", and "File Transfer" (which is highlighted). The main area features a "File Transfer" header and a central dialog box. This dialog box includes an information icon and the text "F/W Version : TEST02 SPE 111423". Below this is a document icon next to a file selection field, followed by a "Download" button. A comment icon is also present. At the bottom of the dialog, there are two labels: "File name :" and "The file size : 0 Byte".



Support file type

: F/W File (.fls)

This menu is only available when connected by USB.

7. Mobile-POS Printer Guide

7-1 Printer Settings

7-1-1 General Settings

This menu supports printer's general option setting.

BIXOLON Utility v1.0.0

Printer Info

- Printer Setting
 - General Settings
 - Interface
 - WLAN Advanced
- NV Image Tool
- File Transfer

General Settings

Speed: 100mm/s

Density: 80%

Media Type: Receipt

Beep for Roll Paper End: Disable

Beep for Low Battery: Enable

Code page: Katakana

Tear-off Position: 272 Units (0~640)

Power Off: 0 Min. (0~90)

Power Save Mode: 0 Sec. (0, 10~255)

Font: ☒ A (12x24) ☐ B (9x17) ☐ C (9x24)

2Bytes Font Mode: ☐ Disable ☒ Enable

MSR: Not used MSR trigger

Advanced

Reset

Save

Close

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

1) Click the Reset button to reset the options.

Windows BIXOLON Utility

Settings	Description
1)Speed	Printing speed
Density	Printing density
2)Media Type	Printer media type - Receipt: Continuous paper not separated - Label: Paper separated by a gap or Blackmark - Blackmark: Paper separated by a Blackmark (Black stripe)
Beep for Roll Paper End	Warning sound of paper empty
Beep for Low Battery	Warning sound of battery low status
Code Page	Printer default code page
Tear-off Position	Adjust tear-off position in label mode
Power off	Power off the printer if it is not used for a setting time If the value is 0, the function is disabled (Disconnect to the host)
Power Save Mode	On the Power Save Mode if it is not used for a setting time If the value is 0, the function is disabled (Still connect to the host)
Font	Printing Font
2Bytes Font Mode	For usage of 2Bytes font
MSR Trigger	Set a method of MSR data scan



- 1) SRP-C200/C300 are only support 50mm/s speed option.
 2) Supported option
 : SRP-C200/C300: Receipt, Blackmark
 Others: Receipt, Label

7-1-2 Interface

This menu supports interface settings such as Serial, Bluetooth.

BIXOLON Utility v1.0.0

Printer Info

Printer Setting

- General Settings
- Interface
- WLAN Advanced

NV Image Tool

File Transfer

Interface

Serial

Baud Rate: 19200

Data Bits: 8

Parity: None

Stop Bits: 1

☒ **Bluetooth**

Device Name: SPP-R200III

PIN Code: 0000

Authentication & Encryption: Disable

Connection Mode: Mode 2

Reset

Save

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Close


1) If you want the Bluetooth setting, please check the box.

2) Please reboot the printer after option save.

Settings	Description
Device Name	Device name displayed during BT pairing
PIN Code	Code required during BT pairing
Authentication & Encryption	If Authentication & Encryption mode is disabled, connection to a device can be done without a Code
Connection Mode	<ul style="list-style-type: none"> - Mode 1: connection possible only with the first device with which connection succeeds - Mode 2: connection with all Bluetooth enabled devices possible via use of a PIN Code - Mode 3: Discovery will be not supported. Use MAC address for connection

7-2 NV Image Tool

- This menu supports NV image download to the printer flash memory.



7-2-1 Add the NV Image

Please add an image.

NV Image Tool

Download

No.	Name	Size
1	BIXOLON.bmp	2262 Bytes


Add

Remove

Remove All

☐ Address (Auto)

Download






Supported file type
Bitmap file (.bmp)


7-2-2 Download the NV Image

Please download the image.



7-2-3 Print the NV Image

Please select the item and click the print button.



7-3 File Transfer

- This menu supports transfer a file to the printer.

BIXOLON Utility v1.0.0

Printer Info

> Printer Setting

NV Image Tool

Command Test

File Transfer

File Transfer

F/W Version :

TEST02 SPE 111423

File name :

The file size : 0 Byte

Download

Close

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.



Support file type

F/W File (.fls)

This menu is only available when connected by USB.

8. Label / Mobile-Label Printer Guide

8-1 Printer Settings

8-1-1 General Settings

This menu supports printer's general option setting.

BIXOLON Utility v1.0.0

Printer Setting

- General Settings
- Language
- Interface
- Real-Time Clock
- Power
- RFID
- Statistics / USB
- WLAN Advanced

Calibration Settings

Print Quality Settings

Downloader

Printer Tool

Command Test

General Settings

Settings

Width: 812 ☐

Height: 1218 ☐

Print Orientation: Bottom to Top

Speed: 5.0 ☐

Density: 0 ☐

Print Method: Direct

Media Type: Continuous ☐

Adjustment(Tear-Off): 0 ☐

Printer Offset: 0 ☐

Advanced

Cutting Mode: Cutter

Feed: No feed

Back-Feeding Mode: Default settings

Setting Unit : dots

File Save Refresh Save

BIXOLON Copyright (c) BIXOLON CO., LTD. All Rights Reserved. Close

- 1) You can set the option lock by checking the check box next to each option.
- 2) You can save the currently option as a command file by clicking the Save File button.



Depending on the printer model, the type, range of options may vary.
 If you set the command lock, sending the command doesn't change the option.
 CMD file default path : C:\BIXOLON\BIXOLON_Utility\Setting files
 You can transfer CMD file to the printer in [Downloader->File Transfer](#) menu.

Windows BIXOLON Utility

Settings	Description
Width	Printing paper width
Height	Printing paper height
Print Orientation	Printing paper orientation
Speed	Printing speed
Density	Printing density
Print Method	- Direct: Printing by applying heat to special media - Transfer: Printing with a black object called a ribbon
Media Type	- Gap: Paper separated by a gap (certain space) - Continuous: Paper not separated - Blackmark: Paper separated by a Blackmark (Black stripe)
Adjustment(Tear-Off)	Adjust tear-off of paper after print
Printer Offset	Offset length between Gap(or BM) and cutting position
1)Cutting Mode	Set the cutting mode
Feed	Set the end method
Back-Feeding Mode	Set the back-feeding mode
2)Emulation	Printer emulation


Depending on the printer model, the range of options may vary.



- 1) Please don't select the 'Cutter' option on the printer not equipped with a cutter.
- 2) Supported model : SRP-S3000

8-1-2 Language

This menu supports option setting regarding to codepage/Int'l Char Set.



1) You can save the currently option as a command file by clicking the Save File button.



Depending on the printer model, the type, range of options may vary.
If you set the command lock, sending the command doesn't change the option.
CMD file default path: C:\BIXOLON\BIXOLON_Utility\Setting files
You can transfer CMD file to the printer in [Downloader->File Transfer](#) menu.

8-1-3 Interface

This menu supports interface settings such as Serial, Bluetooth.

The screenshot shows the 'Interface' settings window of the BIXOLON Utility v1.0.0. The window has a sidebar on the left with a tree view containing 'Printer Info', 'Printer Setting' (expanded), 'Calibration Settings', 'Print Quality Settings', 'Downloader', 'Printer Tool', and 'Command Test'. Under 'Printer Setting', there are sub-items: 'General Settings', 'Language', 'Interface' (selected), 'Real-Time Clock', 'Power', 'RFID', 'Statistics / USB', and 'WLAN Advanced'. The main area is titled 'Interface' and contains two sections: 'Bluetooth' and 'Serial'. The 'Bluetooth' section has a checked checkbox, a 'USB Dongle Type' checkbox, and fields for 'Device Name' (XD5-40tR), 'PIN Code' (0000), 'MAC Address', 'Authentication & Encryption' (Enable), 'Connection Mode' (Mode 2), 'Role Mode', 'Pairing Mode' (PIN Code), and a 'Get' button. The 'Serial' section has a checked checkbox and dropdown menus for 'Baud Rate' (115200), 'Data Bits' (8), 'Parity' (None), 'Stop Bits' (1), and 'Flow Control' (Hardware). At the bottom right of the main area are 'Default', 'Refresh', and 'Save' buttons. The footer contains the BIXOLON logo, copyright information 'Copyright (c) BIXOLON CO., LTD. All Rights Reserved.', and a 'Close' button.

BIXOLON Utility v1.0.0

Interface

☒ Bluetooth

☐ USB Dongle Type

Device Name: XD5-40tR

PIN Code: 0000

MAC Address:

Authentication & Encryption: Enable

Connection Mode: Mode 2

Role Mode:

Pairing Mode: PIN Code

Get

☒ Serial

Baud Rate: 115200

Data Bits: 8

Parity: None

Stop Bits: 1

Flow Control: Hardware

Default

Refresh

Save

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Close

- 1) If you want the setting, please check the box.
- 2) Click the Default button to set the default value.

8-1-4 Real-Time Clock

This menu supports settings regarding to Real-Time Clock.

The screenshot shows the 'Real-Time Clock' settings window within the BIXOLON Utility v1.0.0 application. The left sidebar contains a tree view with the following items: 'Printer Info', 'Printer Setting' (expanded), 'General Settings', 'Language', 'Interface', 'Real-Time Clock' (selected), 'Power', 'RFID', 'Statistics / USB', 'WLAN Advanced', 'Calibration Settings', 'Print Quality Settings', 'Downloader', 'Printer Tool', and 'Command Test'. The main area is titled 'Real-Time Clock' and contains a settings panel with the following options: 'Real-Time Clock' (checked), 'Set Real-Time Clock to computer's clock' (unchecked), and 'Manual' (selected). Below these options are two input fields: a date field showing '2023-12-06' and a time field showing '오후 6:29:20'. A 'Save' button is located at the bottom right of the settings panel. The bottom of the window features the BIXOLON logo, the copyright notice 'Copyright (c) BIXOLON CO., LTD. All Rights Reserved.', and a 'Close' button.

BIXOLON Utility v1.0.0

Real-Time Clock

☒ Real-Time Clock
☐ Set Real-Time Clock to computer's clock
☒ Manual

2023-12-06 오후 6:29:20

Save

BIXOLON Copyright (c) BIXOLON CO., LTD. All Rights Reserved. Close

8-1-5 Power

This menu supports settings regarding to Power Save Mode.

BIXOLON Utility v1.0.0

Printer Info

▼ Printer Setting

- General Settings
- Language
- Interface
- Real-Time Clock
- Power
- RFID
- Statistics / USB
- WLAN Advanced

Calibration Settings

Print Quality Settings

► Downloader

Printer Tool

Command Test

Power

Power Off Disable (1~90) 0 Min.

Power Save Mode Disable (1~255) 0 Sec.

File Save Refresh Save

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Close

1) You can save the currently option as a command file by clicking the Save File button.

Supported models

: SRP-S3000, XM7-20, XM7-30, XM7-40, SPP-L3000, SRP-L310, SPP-L410



CMD file default path: C:\BIXOLON\BIXOLON_Utility\Setting files

You can transfer CMD file to the printer in [Downloader->File Transfer](#) menu.

8-1-6 RFID

This menu supports settings regarding to RFID.

BIXOLON Utility v1.0.0

Printer Info

▼ Printer Setting

- General Settings
- Language
- Interface
- Real-Time Clock
- Power
- RFID
- Statistics / USB
- WLAN Advanced

Calibration Settings

Print Quality Settings

> Downloader

Printer Tool

Command Test

RFID

Tag Type

Class1 GEN2

Writing Power

10

Transponder Position

100

Number of Retries

1

Number of Labels

3

Default

Refresh

Save

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Close



This menu is available only for printers that support RFID.
Ex Model: XM7-40R, XD5-40tR etc.

8-1-7 Statistics/USB

This menu supports check the statistics data or set the USB Serial Number.

The screenshot displays the BIXOLON Utility v1.0.0 interface. The title bar is orange with the text "BIXOLON Utility v1.0.0". The left sidebar contains the following menu items: "Printer Info", "Printer Setting" (expanded), "- General Settings", "- Language", "- Interface", "- Real-Time Clock", "- Power", "- RFID", "- Statistics / USB" (highlighted), "- WLAN Advanced", "Calibration Settings", "Print Quality Settings", "> Downloader", "Printer Tool", and "Command Test". The main area is titled "Statistics / USB" and contains three data rows, each with a "Reset" button:

Statistics	Value	Action
Motor Feeding :	00176.45 M	Reset
(P) Motor Feeding :	00176.45 M	
TPH :	00176.45 M	Reset
(P) TPH :	00176.45 M	
Auto Cutting :	0000263 times	Reset
(P) Auto Cutting :	0000263 times	

Below the statistics, there is a section for "USB S/N" with an input field and a "Set" button. A note "(P) : Permanent" is located at the bottom right of the statistics area. The footer of the window includes the BIXOLON logo, the copyright notice "Copyright (c) BIXOLON CO., LTD. All Rights Reserved.", and a "Close" button.

1) Click the Initialize button for each data to initialize the data.

2) Input an USB Serial Number and click the set button to set the USB S/N.

8-2 Calibration Settings

This menu supports manually calibrate the printer calibration.

BIXOLON Utility v1.0.0

Printer Info
 > Printer Setting
Calibration Settings
 Print Quality Settings
 > Downloader
 Printer Tool
 Command Test

Calibration Settings

Sensing Value

<input type="radio"/> 32 : 0000	<input type="radio"/> 800 : 0000
<input type="radio"/> 64 : 0000	<input type="radio"/> 832 : 0000
<input type="radio"/> 96 : 0000	<input type="radio"/> 864 : 0000
<input type="radio"/> 128 : 0000	<input type="radio"/> 896 : 0000
<input type="radio"/> 160 : 0000	<input type="radio"/> 928 : 0000
<input type="radio"/> 192 : 0000	<input type="radio"/> 960 : 0000
<input type="radio"/> 224 : 0000	<input type="radio"/> 992 : 0000
<input type="radio"/> 256 : 0000	<input type="radio"/> 1024 : 0000
<input type="radio"/> 288 : 0000	
<input type="radio"/> 320 : 0000	
<input type="radio"/> 352 : 0000	
<input type="radio"/> 384 : 0000	
<input type="radio"/> 416 : 0000	
<input type="radio"/> 448 : 0000	
<input type="radio"/> 480 : 0000	
<input type="radio"/> 512 : 0000	
<input type="radio"/> 544 : 0000	
<input type="radio"/> 576 : 0000	
<input type="radio"/> 608 : 0000	
<input type="radio"/> 640 : 0000	
<input type="radio"/> 672 : 0000	
<input type="radio"/> 704 : 0000	
<input type="radio"/> 736 : 0000	
<input type="radio"/> 768 : 0000	

Step 1

Media Type

☒ Gap
☐ Blackmark

Label Length

150 (mm)

Value Check

Step 2

Middle Value

0

Gap Count

7

Save

Cancel

Cancel Calibration

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

Close

- 1) After selecting Media Type and entering Label Length, click the Value Check button.
- 2) Click the Save button that selects the sensing value among the sensor detection values.
- 3) If the printer do not detect the paper properly, select a different value and save it.
- 4) Click the cancel calibration button to set up to default.



Please enter the label length at least 3 to 4 times the length of the paper in use. This menu is available after automatic calibration
 Use when paper (gap or blackmark) is not recognized.

8-3 Print Quality Settings

- You can check and set print quality by printing samples according to print quality.

BIXOLON Utility v1.0.0

Printer Info
➤ Printer Setting
Calibration Settings
Print Quality Settings
➤ Downloader
Printer Tool
Command Test

Print Quality Settings

☐ Auto
Number of Labels: 0

☒ Manual
Speed: 3.0 inch/s
Density: 8
Test Print

Identifier: [Dropdown]
Speed : 3.0 inch/s
Density : 8
☐ Save as
Set

BIXOLON
Copyright (c) BIXOLON CO., LTD. All Rights Reserved.
Close

- Auto

- 1) Select Number of Labels.
- 2) Click the test print button to print the sample at any speed and concentration.
- 3) After checking the print, select the identifier and click the set button.


- Manual

- 1) Select the Speed/Density.
- 2) Please click the test print and check the print.
- 3) When you Click the set button, the value applies.

8-4 Downloader

8-4-1 PCX Files

Please download the image.



- Image Save(IS)

- 1) Select the image you want to download to printer.
- 2) Input the image name and click the download button.

- Image Info(II)

- 1) Print the saved image information by clicking the button.

Windows BIXOLON Utility

- Image Delete(ID)

- 1) Input the image name to delete.
- 2) Click the Delete button or Delete All button.

- Image Recall(IR)

- 1) Input the image name and position you want to print and click the recall image button.




Supported file type

: pcx, bmp, jpg

8-4-2 Image Files

Please download the image.




- 1) Open the file to download to the printer.
- 2) Set the file name and option and click the download button.
- 3) Click the Re button to reset the image option.
- 4) Select the item in the list and click the Test Print button to print image.



The image stored in Storage R: will lose data when the printer is turned off.

8-4-3 TTF → Bitmap Font

This menu supports the function of converting TTF to Bitmap font.



- Download the font

1) Click the TTF Button to open the TTF.

2) Set the Font Name and options and click the Download button.

- Print the saved font.

1) Input the Font Name and click the Sample Text button.

8-4-4 TTF → Vector Font

This menu supports the function of converting TTF to Vector font.

BIXOLON Utility v1.0.0

Printer Info
Printer Setting
Calibration Settings
Print Quality Settings
▼ Downloader
- PCX Files
- Image Files
- TTF → Bitmap font
- TTF → Vector font
- BAS Files
- File Transfer
Printer Tool
Command Test

TTF → Vector font

TTF (True Type Font)
Arial (1012 KB) ...

Vector font
Font Name font . FNT
Storage R:
Free Space KB

Download

Storage	File Name	File Size (KB)
---------	-----------	----------------

Get Test Print Remove

BIXOLON Copyright (c) BIXOLON CO., LTD. All Rights Reserved. Close

1) Select the TTF to convert.

2) Set the Font Name and Storage and click the Download button.



The image stored in Storage R: will lose data when the printer is turned off.

Windows BIXOLON Utility

Fonts have been downloaded to the printer can be used through the emulation.

- Bitmap Font

Desktop/Industrial	SLCS
Mobile-Label/SRP-S3000_LABEL	SLCS, BPL-C

- Vector Font

Desktop/Industrial	BPL-Z
Mobile-Label/SRP-S3000_LABEL	.fnt /.ttf / .tte : BPL-Z .csf : BPL-C



Please note that some True Type fonts are subject to copyright protection, and you must comply with the terms of use and copyright notices for the fonts you want to use.

BIXOLON is not responsible for any direct or indirect damages, arising from or related to use of True Type fonts.

When convert to bitmap font, it may not support all or part of the supported code page depending on the TTF.

Not supported characters are displayed to empty characters.

8-4-5 BAS Files

This menu supports download the BAS file.

BIXOLON Utility v1.0.0

BAS Files

Download (*.BAS)

File Name : None
File Size : 0 Byte

BAS :

Storage : E:

Information

Storage	BAS File Name
---------	---------------

Print

Storage : E:

Delete

Storage : E:

BAS :

XI (BIXOLON Interpreter)

Storage : E:

BAS :

BIXOLON

Copyright (c) BIXOLON CO., LTD. All Rights Reserved.

- Download the file

1) Open the file to save.

2) Set the File Name and Storage and click the Download button.

- File Information

1) Click the Print button to print BAS file information.

2) Click the Get button to get the list of BAS file.



To use Storage A: you must insert a USB memory into the printer.

Windows BIXOLON Utility

- Delete file


- 1) Select the storage.
- 2) Input the File Name and click the Delete button.

- XI

- 1) Set the File Name and Storage.
- 2) Click the Start button to start XI Mode with the BAS file.
- 3) Click the End button to end XI Mode.

8-4-6 File Transfer

This menu supports File Merge and transfer file to the printer.



- File Merge

- 1) Click the Open Folder button to open files to merge.
- 2) After set the file order, click the File Merge button.

- File Transfer


- 1) Open the file to transfer to the printer.



F/W file transfer is available when connected by USB.
File contents must be written by printer command.

8-5 Printer Tool

- You can check the printer information or perform the specified function.



- Print

- 1) Click the setting Info button to print printer setting information.
- 2) Click the object List button to print list of objects stored on printer.

- Diagnostics Mode

: The printer can print the data it receives as ASCII or Hex data.

- Others

- : Click the Auto Calibration to adjust the sensor value according to the paper size and type.
- : Click the Reset button to reset the printer settings.

8-6 Command Test

- This menu supports command test.

BIXOLON Utility v1.0.0

Printer Info
Printer Setting
Calibration Settings
Print Quality Settings
Downloader
Printer Tool
Command Test

Command Test

Utility → XD5-40tR

Command: 1
Send Clear

Files: Save Load

XD5-40tR → Utility

Type: ☐ Hex ☒ ASCII
Read Clear

Printer Setting Barcode Line & Box Printer Status
2Bytes Code page Text Character Set RFID

BIXOLON Copyright (c) BIXOLON CO., LTD. All Rights Reserved. Close



You can download the manual on our website and by model
The supported commands may differ.
(www.bixolon.com)

Revision History

[illegible]